Thinking of you

Electrolux

EKC607601

EN COOKER

USER MANUAL

Electrolux. Thinking of you.

Share more of our thinking at www.electrolux.com

CONTENTS

Safety information	2	Oven - Helpful hints and tips	16
Safety instructions	3	Oven - Care and cleaning	23
Product description	6	What to do if…	25
Before first use	6	Installation	26
Hob - Daily use	7	Environment concerns	27
Hob - Helpful hints and tips	10	GREAT BRITAIN & IRELAND - Guarantee/	
Hob - Care and cleaning	11	Customer Service	28
Oven - Daily use	11	European Guarantee	28
Oven - Clock functions	15		

Subject to change without notice.

SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible if an incorrect installation and use causes injuries and damages. Always keep the instructions with the appliance for future reference.

CHILDREN AND VULNERABLE PEOPLE SAFETY

⚠ **Warning!** Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they are supervised by an adult or a person who is responsible for their safety.
- Do not let children play with the appliance.
- Keep all packaging away from children.
- Keep children and pets away from the appliance when it operates or when it cools down. Accessible parts are hot.
- If the appliance has a child safety device, we recommend that you activate it.
- Cleaning and user maintenance shall not be made by children without supervision.

GENERAL SAFETY

- The appliance and its accessible parts become hot during use. Do not touch the heating elements.
- Do not operate the appliance by means of an external timer or separate remote-control system.
- Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.
- Never try to extinguish a fire with water, but switch off the appliance and then cover flame e.g. with a lid or a fire blanket.
- Do not store items on the cooking surfaces.
- Do not use a steam cleaner to clean the appliance.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the hob surface since they can get hot.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass door since they can scratch the surface, which may result in shattering of the glass.
- To remove the shelf supports first pull the front of the shelf support and then the rear end away from the side walls. Install the shelf supports in the opposite sequence.
- If the glass ceramic surface is cracked, switch off the appliance to avoid the possibility of electric shock.

⚠ SAFETY INSTRUCTIONS

INSTALLATION

⚠ **Warning!** Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Obey the installation instruction supplied with the appliance.
- Always be careful when you move the appliance because it is heavy. Always wear safety gloves.
- Do not pull the appliance by the handle.
- Keep the minimum distance from the other appliances and units.
- Make sure that the appliance is installed below and adjacent safe structures.
- The sides of the appliance must stay adjacent to appliances or to units with the same height.
- Do not install the appliance on a platform.
- Do not install the appliance adjacent to a door or under a window. This prevents hot cookware to fall from the appliance when the door or the window is opened.

⚠ **Warning!** Make sure to install a stabilizing means in order to prevent tipping of the appliance. Refer to Installation chapter.

Electrical connection

⚠ **Warning!** Risk of fire and electrical shock.

- All electrical connections should be made by a qualified electrician.
- The appliance must be earthed.
- Make sure that the electrical information on the rating plate agrees with the power supply. If not, contact an electrician.
- Always use a correctly installed shock-proof socket.
- Do not use multi-plug adapters and extension cables.
- Make sure not to cause damage to the mains plug and to the mains cable. Contact the Service or an electrician to change a damaged mains cable.
- Do not let mains cables to come in touch with the appliance door, specially when the door is hot.
- The shock protection of live and insulated parts must be fastened in such a way that it cannot be removed without tools.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- If the mains socket is loose, do not connect the mains plug.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Use only correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.
- The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.

USE

⚠ **Warning!** Risk of injury, burns or electric shock.

- Use this appliance in a household environment.
- Do not change the specification of this appliance.
- Make sure that the ventilation openings are not blocked.
- Do not let the appliance stay unattended during operation.
- Deactivate the appliance after each use.
- Internally the appliance becomes hot when in operation. Do not touch the heating elements that are in the appliance. Always use oven gloves to remove or put in accessories or ovenware.
- Be careful, when you open the appliance door while the appliance is in operation. Hot air can release.
- Do not operate the appliance with wet hands or when it has contact with water.
- Do not apply pressure on the open door.
- Do not use an external timer or a separate remote-control system to operate the appliance.
- Always keep the appliance door closed when the appliance is in operation.
- Do not put cutlery or saucepan lids on the cooking zones. They become hot.
- Set the cooking zone to “off” after use.
- Do not use the appliance as a work surface or as a storage surface.
- If the surface of the appliance is cracked, disconnect immediately the appliance from the power supply. This to prevent an electrical shock.

⚠ **Warning!** Risk of fire or explosion.

- Fats and oil when heated can release flammable vapours. Keep flames or heated objects away from fats and oils when you cook with them.
- The vapours that very hot oil releases can cause spontaneous combustion.
- Used oil, that can contain food remnants, can cause fire at a lower temperature than oil used for the first time.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- Do not let sparks or open flames to come in contact with the appliance when you open the door.
- Open the appliance door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air.
- Do not try to extinguish a fire with water. Disconnect the appliance and cover the flame with a lid or a fire blanket.

⚠ **Warning!** Risk of damage to the appliance.

- To prevent damage or discoloration to the enamel:
  - Do not put ovenware or other objects in the appliance directly on the bottom.
  - Do not put aluminium foil directly on the bottom of the appliance.
  - do not put water directly into the hot appliance.
  - do not keep moist dishes and food in the appliance after you finish the cooking.
  - be careful when you remove or install the accessories.
- Discoloration of the enamel has no effect on the performance of the appliance. It is not a defect in the sense of the warranty law.
- Use a deep pan for moist cakes. Fruit juices cause stains that can be permanent.
- Do not keep hot cookware on the control panel.
- Do not let cookware to boil dry.
- Be careful not to let objects or cookware fall on the appliance. The surface can be damaged.
- Do not activate the cooking zones with empty cookware or without cookware.
- Do not put aluminium foil on the appliance.
- Cookware made of cast iron, aluminium or with a damaged bottom can cause scratches on the glass ceramic. Always lift these objects up when you have to move them on the cooking surface.

⚠ **Warning!** This appliance is for cooking purposes only. It must not be used for other purposes, for example room heating.

CARE AND CLEANING

⚠ **Warning!** Risk of injury, fire or damage to the appliance.

- Before maintenance, deactivate the appliance and disconnect the mains plug from the mains socket.
- Make sure the appliance is cold. There is the risk that the glass panels can break.
- Replace immediately the door glass panels when they are damaged. Contact the Service.
- Be careful when you remove the door from the appliance. The door is heavy!
- Clean regularly the appliance to prevent the deterioration of the surface material.
- Remaining fat or food in the appliance can cause fire.
- Clean the appliance with a moist soft cloth. Only use neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- If you use an oven spray, obey the safety instructions on the packaging.
- Do not clean the catalytic enamel (if applicable) with any kind of detergent.

INTERNAL LIGHT

- The type of light bulb or halogen lamp used for this appliance, is only for household appliances. Do not use it for house lighting.

⚠ **Warning!** Risk of electrical shock.

- Before replacing the lamp, disconnect the appliance from the power supply.
- Only use lamps with the same specifications.

SERVICE

- Contact the Service to repair the appliance. We recommend only the use of original spare parts.

DISPOSAL

⚠ **Warning!** Risk of injury or suffocation.

- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.
- Remove the door catch to prevent children and pets to get closed in the appliance.

PRODUCT DESCRIPTION

GENERAL OVERVIEW



1 Hob
2 Air vents for cooling fan
3 Heating element
4 Oven lamp
5 Rating plate
6 Heating element
7 Oven lamp
8 Fan
9 Shelf positions of the main oven
10 Shelf positions of the top oven

COOKING SURFACE LAYOUT



1 Single cooking zone 1200 W
2 Double cooking zone 700/1700 W
3 Single cooking zone 1800 W
4 Oven Control panel
5 Hob control panel
6 Triple cooking zone 800/1600/2300 W

ACCESSORIES

- **Deep grill roasting pan**
  To bake and roast or as pan to collect fat.
- **The roasting pan grid**
  To put in the deep roasting pan.
- **Oven shelf**
  For cookware, cake tins, roasts.

BEFORE FIRST USE

⚠ **Warning!** Refer to the Safety chapters.

Important! Refer to chapter "Care and Cleaning".

INITIAL CLEANING

- Remove all parts from the appliance.
- Clean the appliance before first use.

SENSOR FIELD

Touch and hold for minimum 1 second the sensor field on the control panel to operate the appliance.



SETTING THE TIME

The oven only operates after time set.

When you connect the appliance to the electrical supply or in case of a power cut, the Time function indicator flashes automatically.
To set the current time use ⚠ or ▽ button. After approximately 5 seconds, the flashing stops and the display shows the time of day set.

You can only change the Time of day ◴ if :

- the switch-on lock is not on
- none of the clock functions Duration I→I or End →I is set
- no oven function is set.

PRE-HEATING

1. Set function ▭ and maximum temperature.
2. Let the appliance operate without the food for approximately 1 hour.
3. Set function ▭ and maximum temperature.
4. Let the appliance operate without the food for approximately 10 minutes.
5. Set function ♨ and maximum temperature.
6. Let the appliance operate without the food for approximately 10 minutes.

This is to burn off the residue in the appliance. The accessories can become more hot than usually. When you pre-heat the appliance for the first time, the appliance can make an odour and smoke. This is the usual effect. Make sure the airflow is sufficient.
Preheat the two ovens. Heat up one oven at a time.

HOB - DAILY USE

⚠ **Warning!** Refer to the Safety chapters.

CONTROL PANEL LAYOUT



Use the sensor fields to operate the appliance.

	sensor field	function
1	with an indicator	locks/unlocks the control panel
2	/	increase or decrease heat setting / time
3	a heat setting display	shows the heat setting
4	cooking zone's indicators of timer	shows for which zone you set the time
5	the timer display	shows the time in minutes
6		starts double zone
7		selects the time for cooking zone
8		starts double and triple zone
9	STOP + GO	starts and stops the STOP&GO function
10		starts and stops the hob

HEAT SETTING DISPLAYS

Display	Description
0	The cooking zone is off
1 - 9	The cooking zone operates
u	Keep warm setting is on
F	The induction cooking zone does not sense the cookware
E	There is a malfunction
H	A cooking zone is still hot (residual heat)
L	Key Lock/Child Lock is on
P	Power function is active
A	The automatic heat-up function is on

ON AND OFF

Touch for 2 seconds to start the appliance. Touch for 1 second to stop the appliance.

THE HEAT SETTING

Touch to increase the heat setting. Touch to decrease the heat setting. The display shows the heat setting. Touch and at the same time to switch off the cooking zone.

AUTOMATIC HEAT UP



You can get a necessary heat setting in a shorter time if you activate the Automatic Heat Up function. This function sets the highest heat setting for some time (see the graphic), and then decreases to the necessary heat setting.
To start the Automatic Heat Up function:

1. Touch ▽ . [9] comes on in the display.
2. Touch △ again and again until [A] comes on in the display.
3. Immediately touch ▽ again and again until the necessary heat setting comes on. After 3 seconds [A] comes on in the display.

To stop the function touch ▽ .

POWER MANAGEMENT

Operating both ovens and the four hob zones at the same time can activate the power management system, which will deactivate one or more of the hob heating zones. This is a power regulation within the appliance to prevent a circuit overload

USING THE TIMER

Use the timer to set how long the cooking zone operates for one cooking session.
Set the timer after the selection of the cooking zone.
You can set the heat setting before or after you set the timer.

- **Selection of the cooking zone:**touch ◴ again and again until the indicator of a necessary cooking zone comes on.
- **Starting and changing the timer:** touch △ or ▽ of the cooking zone to set the time (00 - 99 minutes). When the indicator of the cooking zone flashes slower, the time counts down.
- **Stopping the timer:** select the cooking zone with ◴ and touch ▽ to switch off the timer. The remaining time counts backwards to 00 . The indicator of the cooking zone goes out. You can also touch △ and ▽ at the same time to switch off the timer.
- **Checking the remaining time:** select the cooking zone with ◴ . The indicator of the cooking zone flashes faster. Display shows the remaining time.

When the time elapses, the sound operates and 00 flashes. The cooking zone switches off.

- **Stopping the sound:** touch ◴ .

You can use the timer as a **minute minder** while cooking zones do not operate. Touch ◴ . Touch △ or ▽ to select the time.
When the time elapses, the sound operates and 00 flashes

STOP+GO STARTING THE STOP+GO

The STOP+GO function sets all cooking zones that operate to a keep warm setting.

- **Touch STOP+GO to start** this function. The symbol [u] comes on.
- **Touch STOP+GO to stop** this function. The heat setting that you set before comes on.

STOP+GO does not stop the timer function.
STOP+GO locks the control bars.

LOCKING / UNLOCKING THE CONTROL PANEL

You can lock the control panel, but not ⏻ . It prevents an accidental change of the heat setting during a cooking session.
First set the heat setting.
Touch the symbol 🔒 . The symbol [L] comes on for 4 seconds.
The Timer still operates.
Touch the symbol 🔒 to switch off this function. The heat setting that you set before comes on.
When you switch off the appliance, you also switch off this function.

ⓘ The locking / unlocking function locks or unlocks the oven interface at the same time.

THE CHILD SAFETY DEVICE

This function prevents an accidental operation of the hob and oven.

Starting the child safety device

- Start the hob with ⏻ . **Do not set the heat settings**.
- Touch 🔒 for 4 seconds. Acoustic signal appears. The symbol [L] comes on the hob and the symbol **"SAFE"**on the oven display.
- Stop the hob with ⏻ .

Switching off the child safety device

- Start the hob with ⏻ . **Do not set the heat settings**. Touch 🔒 for 4 seconds. Acoustic signal appears. The symbol 0 comes on the hob and the symbol **"SAFE"** goes out of the oven display.
- Stop the hob with ⏻ .

ℹ The child safety device function locks the hob and oven at this same time.

RESIDUAL HEAT INDICATOR

The residual heat indicator comes on when a cooking zone is hot.

⚠ **Warning!** Risk of burns from residual heat!

HOB - HELPFUL HINTS AND TIPS

⚠ **Warning!** Refer to the Safety chapters.

COOKWARE

ℹ
- The bottom of the cookware must be as thick and flat as possible.
- Cookware made of enamelled steel and with aluminium or copper bottoms can cause discoloration on glass ceramic surface.

ENERGY SAVING

- If possible, always put the lids on the cookware.
- Put cookware on a cooking zone before you start it.
- Stop the cooking zones before the end of the cooking time to use residual heat.
- The bottom of pans and cooking zones must have the same dimension.

EXAMPLES OF COOKING APPLICATIONS

The data in the table is for guidance only.

Heat setting	Use to:	Time	Hints
⏑ 1	Keep cooked foods warm	as required	Cover
1-2	Hollandaise sauce, melt: butter, chocolate, gelatine	5-25 min	Mix occasionally
1-2	Solidify: fluffy omelettes, baked eggs	10-40 min	Cook with a lid on
2-3	Simmer rice and milkbased dishes, heating up ready-cooked meals	25-50 min	Add at least twice as much liquid as rice, stir milk dishes part way through
3-4	Steam vegetables, fish, meat	20-45 min	Add a few tablespoons of liquid
4-5	Steam potatoes	20-60 min	Use max. ¼ l water for 750 g of potatoes
4-5	Cook larger quantities of food, stews and soups	60-150 min	Up to 3 l liquid plus ingredients
6-7	Gentle fry: escalope, veal cordon bleu, cutlets, rissoles, sausages, liver, roux, eggs, pancakes, doughnuts	as required	Turn halfway through
7-8	Heavy fry, hash browns, loin steaks, steaks	5-15 min	Turn halfway through
9	Boil large quantities of water, cook pasta, sear meat (goulash, pot roast), deep fry chips		

HOB - CARE AND CLEANING

Warning! Refer to the Safety chapters.

Clean the appliance after each use.
Always use cookware with clean bottom.

Scratches or dark stains on the glass ceramic have no effect on how the appliance operates.

To remove the dirt:

1. – **Remove immediately:**melted plastic, plastic foil, and food with sugar. If not, the dirt can cause damage to the appliance. Use a special scraper for the glass . Put the scraper on the glass surface at an acute angle and move the blade on the surface .
   – **Remove after the appliance is sufficiently cool:**limescale rings , water rings, fat stains, shiny metallic discolorations. Use a special cleaning agent for glass ceramic or stainless steel.
2. Clean the appliance with a moist cloth and some detergent.
3. At the end **rub the appliance dry with a clean cloth.**

OVEN - DAILY USE

Warning! Refer to the Safety chapters.

CONTROL PANEL



Number	Button	Function	Description
1	–	Display	Shows current settings of the oven.
2	▽ △	Setting buttons	To set the value for the temperature and time.
3	↵	Selection/Clock function button	To set a clock function.
4	°C»	Temperature button	To show an oven temperature.

Number	Button	Function	Description
5	∨	Oven function selection	To set an oven function or programme.
6	⇕	Oven selection	To switch between top and main oven.
7	⏻	On/Off	To set the oven on or off.

INDICATORS OF DISPLAY



Number	Name	Description
1	Top/Main oven indicator	Shows which oven operates.
2	Oven function indicator	Shows the function.
3	Lamp/Defrost indicator	Shows the Lamp/Defrost function is active.
4	Heat indicator	Shows the heat setting.
5	Temperature/Clock indicator	Shows the temperature and the time in minutes.
6	Keep warm indicator	Shows that keep warm function is active.
7	Cooking time/End time/ Period of operation	Shows the time setting for clock functions.
8	Clock function indicator	To set the clock function and minute minder.

SWITCHING THE APPLIANCE ON AND OFF

Press the On/Off button ⏻ to switch the appliance on or off.

Top oven functions

Oven function		Application
	Conventional Cooking	To bake and roast on one oven level.
	Browning	To brown.
	Bottom heat	To bake cakes with crispy or crusty bases. To preserve food.

Oven function		Application
	Dual Circuit Grill	To toast or grill flat food in large quantities.
	Light	To light up the oven interior.

Bottom (main) oven functions

Oven function		Application
	Thermaflow®	To bake on 2 oven levels maximum at the same time. Set the oven temperatures 20-40 °C lower than for Conventional.
	Conventional Cooking	To bake and roast on one oven level.
	Pizza Setting	To bake on one oven level with a more intensive browning and a crispy base. Set the oven temperatures 20-40 °C lower than when using Conventional.
	Low Temperature Cooking	To prepare very lean, tender roasted food.
	Thermal Grill	To roast larger joints of meat or poultry on one shelf position. To brown.
	Dual Circuit Grill	To grill flat food in large quantities. To toast bread.
	Keep Warm	To keep food warm.
	Drying	To dry food.
	Defrost	To defrost frozen food.
	Light	To light up the oven interior.

SELECTING AN OVEN

1. Switch on the appliance using the On/ Off ⏻ button.
2. Press the ⇳ button repeatedly until the desired oven appears (Top / Main)

SETTING THE OVEN FUNCTION

Use ∨ to set the oven function.
The display shows the recommended temperature.

If you do not change this temperature in less than approximately 5 seconds, the appliance starts to heat.

When the appliance operates at the set temperature, an acoustic signal sounds.

You can change the oven function while the oven operates.

CHANGING THE OVEN TEMPERATURE

Use ⨁ or ⨂ to set the temperature.

SWITCHING OFF THE OVEN FUNCTION

Use ⋁ again and again, until the display does not show an oven function.

HEAT- UP INDICATOR

If you switch on an oven function, the bars on the display come on one by one. The bars show that the oven temperature increases.

RESIDUAL HEAT INDICATOR

When you switch off the oven, the bars on the display show the residual heat.

RAPID HEAT-UP FUNCTION

To decrease the pre-heating time of the empty oven.

You can use the Rapid heat-up function with the oven functions: True fan , Fan baking , Conventional and Rotitherm .

Important! Do not put the food in the oven, until the Rapid heat-up function is completed

1. Set an oven function.
2. Use the Rapid heat-up button °C» . When the oven has the set temperature, the bars of the heat indicator come up and an acoustic signal sounds. The oven continues to heat with the set oven function and temperature.
3. Put the food in the oven.

RAPID HEAT-UP INDICATOR

If you switch on the RAPID HEAT UP function, the bars on the display flash one by one to show that the function operates.

COOLING FAN

When the appliance operates, the cooling fan switches on automatically to keep the surfaces of the appliance cool. If you switch off the appliance, the cooling fan continues to operate until the appliance cools down.

If there is a fault in the cooling fan, contact the customer service.

THE CHILD SAFETY DEVICE

Refer to "Hob - Daily Use" chapter and "The child safety device" section.

AUTOMATIC CUT-OUT

The appliance switches off after some time:

- if you do not switch off the appliance;
- if you do not change the oven temperature.

The last temperature set flashes in the temperature display.

Oven temperature	Switch-off time
30 °C -120 °C	12.5 h.
120 °C - 200 °C	8.5 h.
200 °C -250 °C	5.5 h.
250 °C -maximum °C	3.0 h.

After an automatic cut-out, switch off the oven fully. Then you can switch it on again.

Important! If you set the clock function Duration I→I or End →I , the automatic cut-out switches off.

INSERTING THE OVEN ACCESSORIES

Put in the slide-in accessories so that the double side edges are at the back of the oven and point down to the bottom. Push the slide-in accessories between the guide-bars of one of the oven levels.



The deep roasting pan and the oven shelf have double side edges. These edges and the shape of the guide-bars causes the anti-tilt safety for the oven accessories.



Inserting the oven shelf and deep roasting pan together

Put the oven shelf on the deep roasting pan. Push the deep roasting pan between the guide-bars of one of the oven levels.

GRILLING SET

The grilling set includes the roasting pan grid and the deep roasting pan.

You can use the roasting pan grid in two positions: turned up and down.

To roast larger pieces of meat or poultry on one level:

1. Put the roasting pan grid in the deep roasting pan. The supports of the roasting pan grid must point up.



2. Put the deep roasting pan in the appliance, on the necessary shelf level.

To grill flat dishes in large quantities and to toast:

1. Put the roasting pan grid in the deep roasting pan. The supports of the roasting pan grid must point down.



2. Put the deep roasting pan in the appliance, on the necessary shelf level.

OVEN - CLOCK FUNCTIONS

SYMBOL	FUNCTION	DESCRIPTION
🔔	Minute Minder	To set a countdown (max. 99 minutes). This function has no effect on the operation of the appliance.
|→|	Duration	To set how long the appliance has to be in operation.

SYMBOL	FUNCTION	DESCRIPTION
→|	End	To set the switch-off time for an oven function. You can use Duration and End at the same time, if the appliance is to be switched on and off automatically later.
🕘	Time of day	To set, change or control the time of day.

- If you set a clock function, the symbol flashes for approximately 5 seconds. In these 5 seconds, touch ⊕ or ⊖ to set the time.
- If you set the time, the symbol continues to flash for approximately 5 seconds. After these 5 seconds, the symbol comes on. The time starts to count down.

SETTING THE CLOCK FUNCTIONS

1. Switch on the appliance.
2. Use ⮐ again and again until the display shows the necessary clock function and the related symbol, for example Minute Minder 🔔 .
3. Use ⊕ or ⊖ to set the necessary time.
   You can hear an acoustic signal for 2 minutes when the time is completed, “00.00” and the related function indicator flash. The appliance switches off.
4. Use any button to switch off the acoustic signal.

ⓘ With Minute Minder 🔔 the oven must be switched on to set the clock function.

ⓘ With Duration |→| and End →| the oven switches off automatically.
With Duration |→| and End →| you must set the oven function and the temperature first, then you can set the clock function.

HEAT+HOLD

To keep the prepared food warm for 30 minutes, after the cooking is completed.

Switching on Heat+Hold

1. Set clock functions Duration |→| and/or End →| .
2. Use Selection ⮐ again and again, until the display shows the symbol Keep warm ≋ .
3. Use ⊕ , the display shows “00:30”
4. When the set oven function is completed, a signal sounds and Heat+Hold starts. The set oven function operates at 80°C for 30 minutes. The oven then switches off automatically.

ⓘ The temperature for the set oven function must be above 80°C.

OVEN - HELPFUL HINTS AND TIPS

⚠ **Warning!** Refer to the Safety chapters.

ⓘ The temperature and baking times in the tables are guidelines only. They depend on the recipes, quality and quantity of the ingredients used.

⚠ **Caution!** Use a Deep grill roasting pan for very moist cakes. Fruit juices can cause permanent stains on the enamel.

TOP OVEN

The top oven is the smaller of the two ovens. It has 3 shelf levels. Use is to cook smaller quantities of food. It gives especially good results when used to cook fruitcakes, sweets and savoury flants or quiche.

MAIN OVEN

The main oven is particularly suitable for cooking larger quantities of food.

BAKING

General instructions

- Your new oven may bake or roast differently to the appliance you had before. Adapt your usual settings (temperature, cooking times) and shelf levels to the values in the tables.
- With longer baking times, the oven can be switched off about 10 minutes before the end of baking time, to use the residual heat.
- Use deep roasting pan in middle or top shelf level of top oven.

- To brown pastry dishes on the bottom, cook on metal plate or put on a baking tray.

When you use frozen food, the trays in the oven can twist during baking. When the trays get cold again, the distortion will be gone.

How to use the Baking Tables

- We recommend to use the lower temperature the first time.
- If you cannot find the settings for a special recipe, look for the one that is almost the same.
- Baking time can be extended by 10-15 minutes, if you bake cakes on more than one level.
- Cakes and pastries at different heights do not always brown equally at first. If this occurs, do not change the temperature setting. The differences equalize during the baking procedure.

Tips on baking

Baking results	Possible cause	Remedy
The cake is not browned sufficiently below	Incorrect oven level	Put the cake on a lower oven level
The cake sinks (becomes soggy, lumpy, streaky)	Oven temperature too high	Use a lower setting
The cake sinks (becomes soggy, lumpy, streaky)	Baking time is too short	Set a longer baking time **Do not set higher temperatures to decrease baking times**
The cake sinks (becomes soggy, lumpy, streaky)	Too much liquid in the mixture	Use less liquid. Look at the mixing times, specially when you use mixing machines
Cake is too dry	Oven temperature too low	Set a higher oven temperature
Cake is too dry	Baking time too long	Set a shorter baking time
Cake does not brown equally	Oven temperature too high and baking time too short	Set a lower oven temperature and a longer baking time
Cake does not brown equally	No equal mixture	Put the mixture equally on the baking tray
Cake does not cook in the baking time set	Temperature too low	Use a slightly higher oven temperature setting

TOP OVEN

CONVENTIONAL BAKING

Food	Shelf Position	Temperature [°C]	Approx Cook Time (mins)
Biscuits	2	170 - 190	10 - 20
Bread	2	200 - 220	30 - 35
Bread rolls/buns	2	200 - 220	10 -15
Cakes: Small & Queen	2	160 - 180	18 - 25
Cakes: Sponges	2	160 - 175	20 - 30
Cakes: Victoria Samdwich	2	160 -170	18 - 25

Food	Shelf Position	Temperature [°C]	Approx Cook Time (mins)
Cakes: Madeira	2	140 - 150	75 - 90
Cakes: Rich Fruit	2	140 - 150	120 - 150
Cakes: Gingerbread	2	140 - 150	80 - 90
Cakes: Meringues	2	90 - 100	150 - 180
Cakes: Flapjack	2	160 - 170	25 -30
Cakes: Shortbread	2	130 - 150	45 - 60
Cakes: Apple Pie	2	170 - 180	50 - 60
Casseroles: Beef/ Lamb	2	160 -170	150 - 180
Casseroles: Chicken	2	160 - 180	80 - 90
Convenience Foods	2	Follow manufacturer`s instructions	
Fish	2	170 - 190	20 - 30
Fish Pie (Potato Topped)	2	190 - 200	20 - 30
Fruit Pies, Crumbles	2	190 - 200	30 - 50
Milk Puddings	2	150 - 170	90 -120
Pasta Lasagne etc.	2	170 - 180	40 -50
Pastry: Choux	2	180 - 190	30 - 40
Pastry: Eclairs, Profiteroles	2	180 - 190	30 - 40
Pastry: Flaky/Puff Pies	2	210 - 220	30 - 40
Shortcrusts: Mince Pies	2	190 - 200	15 - 20
Shortcrusts: Meat Pies	2	190 - 210	25 - 35
Shortcrusts: Quiche, Tarts, Flans	2	180 - 200	25 - 50
Scones	3	220 - 230	8 - 12
Shepard`s Pie	2	190 - 200	30 - 40
Souffles	2	170 - 180	20 - 30
Vegetables: Baked Jacket Potatos	2	180 - 190	60 - 90
Vegetables: Roast Potatos	2	180 - 190	60 - 90
Yorkshire Pudding Large	2	220 - 210	25 - 40
Yorkshire Pudding Individual	2	210 - 220	15 - 25
Roasting Meat, Poultry	2	See roasting chart	

MAIN OVEN

CONVENTIONAL BAKING

Food	Shelf Position	Temperature [°C]	Approx Cook Time (mins)
Biscuits	3	180 - 190	10 - 20
Bread	3	200 - 220	30 - 35
Cakes: Small & Queen	3	160 -180	18 - 25
Cakes: Sponges	3	170 - 180	20 - 25
Cakes: Madeira	3	150 - 160	60 - 80
Cakes: Rich Fruit	2	140 - 150	120 - 150
Cakes: Christmas	2	140 - 150	180 - 270
Cakes: Apple Pie	2	170 - 180	50 - 60
- Shortbread	3	140 - 160	45 - 60
Fish	3	170 - 190	30 - 40
Fruit Pies, Crumbles	3	180 - 200	30 - 50
Milk Puddings	3	150 - 170	60 - 90
Pastry: Choux	3	180 - 190	30 - 40
Pastry: Shortcrust	3	190 - 200	25 - 35
Pastry: Flaky	3	190 - 210	30 -40
Pastry: Puff	3	Follow manufacturer`s instructions. Reduce the temperature for Fan oven by 20°C	
Plate Tarts	3	190 - 200	25 - 45
Quiches/Flans	3	200 - 210	25 - 45
Scones	3	220 - 230	8 - 12
Roasting: Meat, Poultry	3	170 - 190	see Roastinh Chart

THERMAFLOW BAKING

Shelf Positions are not critical but ensure that oven shelves are evenly spaced when more than one is used (e.g. shelf positions 1 and 3)

Food	Shelf Position	Temperature [°C]	Approx Cook Time (mins)
Biscuits	1 – 3	180 - 190	10 - 20
Bread	2	190 - 210	30 - 35
Cakes: Small & Queen	1 – 3	150 - 170	18 - 25
Cakes: Sponges	3	160 - 170	20 - 25
Cakes: Madeira	3	140 - 160	60 - 80
Cakes: Rich Fruit	3	130 - 140	120 - 150
Cakes: Christmas	3	130 - 140	180 - 270
Cakes: Apple Pie	3	160 - 170	50 - 60
- Shortbread	1 – 3	130 - 150	45 - 60
Fish	3	160 - 180	30 - 40
Fruit Pies, Crumbles	3	170 - 180	30 - 50

Food	Shelf Position	Temperature [°C]	Approx Cook Time (mins)
Milk Puddings	3	140 - 160	60 - 90
Pastry: Choux	3	180 - 190	30 - 40
Pastry: Shortcrust	3	180 - 190	25 - 35
Pastry: Flaky	3	180 - 190	30 -40
Pastry: Puff	3	Follow manufacturer`s instructions. Reduce the temperature for Fan oven by 20°C	
Plate Tarts	3	180 - 190	25 - 45
Quiches/Flans	3	170 - 180	25 - 45
Scones	1 – 3	210 - 230	8 - 12
Roasting: Meat, Poultry	2	160 - 180	see Roastinh Chart

PIZZA SETTING

Food	Shelf Position	Temperature	Approx. Cook Time (min)
Apple Pie	2	160 - 180	50 - 60
Plate Tart	2	180 - 200	25 - 50
Pizza, frozen	3	Follow manufacturer`s instructions	
Pizza, home made	2	200 - 230	15 - 25
Quiches/Tarts	2	180 - 200	30 - 50

ROASTING

Roasting dishes

- Use heat-resistant ovenware to roast (please read the instructions of the manufacturer).
- Large roasting joints can be roasted directly in the deep roasting pan or on the oven shelf above the deep roasting pan. (If present)
- Roast lean meats in a roasting tin with a lid. This well keep the meat more succulent.
- All types of meat, that can be browned or have crackling, can be roasted in the roasting tin without the lid.
- Use the deep roasting pan in the middle or the top shelf level of the top oven.

MAIN OVEN

THERMAFLOW OR CONVENTIONAL COOKING (IF AVAILABLE)

Roasting

Meat	Temperature [°C]	Cooking Time
Beef/Beef boned	170 - 190	20-35 minutes per 0.5 kb (1 lb) and 20-30 minutes over
Mutton/Lamb	170 - 190	20-35 minutes per 0.5 kb (1 lb) and 25-35 minutes over
Pork/Veal/Ham	170 - 190	30-40 minutes per 0.5 kb (1 lb) and 30-40 minutes over
Chicken	180 - 200	20-25 minutes per 0.5 kb (1 lb) and 20 minutes over

Meat	Temperature [°C]	Cooking Time
Turkey/Goose	170 - 190	15-20 minutes per 0.5 kg (1 lb) up to 3.5 kg (7 lb) then 10 minutes per 0.5 kg (1 lb) over 3.5 kg (7 lb)
Duck	180 - 200	25-35 minutes per 0.5 kb (1 lb) and 25-30 minutes over
Pheasant	170 -190	35-40 minutes per 0.5 kb (1 lb) and 35-40 minutes over
Rabbit	170 - 190	20 minutes per 0.5 kb (1 lb) and 20minutes over

GRILLING

Always use the grilling function with maximum temperature setting

Important! Always grill with the oven door closed

- Always pre-heat the empty oven with the grill functions for 5 minutes.
  - Set the shelf in the shelf level as recommended in the grilling table.
  - Always set the pan to collect the fat into the first shelf level.
  - Grill only flat pieces of meat or fish.
  - Use the deep roasting pan in the middle or the top shelf level of the top oven.

The grilling area is set in centre of the shelf.



TOP OVEN

DUAL CIRCUIT GRILL

Shelf Position
Adjust shelf position and grilling set to suit different thicknesses of food.

Food	Grill Time (min)
Bacon Rashers	5 - 6
Beefburgers	10 - 20
Chicken Joints	20 - 40
Chops - Lamb	15 - 25
Chops - Pork	20 - 25
Fish - Whole/Trout/Makarel	10 - 12
Fillets - Plaice/Cod	4 - 6
Kebabs	12 -18
Kidneys - Lamb/Pig	6 - 10
Sausages	20 - 30
Steaks: Rare	4 - 6
Steaks: Medium	6 - 8
Steaks: Well Done	12 - 15
Toasted Sandwiches	3 - 4

MAIN OVEN

THERMAL GRILLING

Roasting

Food	Shelf Position	Quantity [kg]	Temperature [°C]	Time (min)
Beef: Pot roast	3		180 - 230	150 - 180
Beef: Topside beef or filler - rare	3	per cm of thickness	190 - 200	5 - 6
Beef: Topside beef or filler - medium	3	per cm of thickness	180 - 190	6 - 8
Beef: Topside beef or filler - well done	3	per cm of thickness	170 - 180	8 - 10
Pork: Shoulder, neck, ham	2	1-1.5	160 - 180	90 - 120
Pork: Pork chop	2	1-1.5	160 - 180	60 - 90
Pork: Meatloaf	2	0.75-1	160 -170	45 - 60
Pork: Knuckle of pork (precooked)	2	0.75-1	150 -170	90 - 120
Veal: Roast veal	2	1	160 - 180	90 - 120
Veal: Knuckle of veal	2	1.5-2	160 -180	120 - 150
Lamb: Roast lamb, leg of lamb	2	1-1.5	150 -170	75 - 120
Lamb: Saddle of lamb	2	1-1.5	160 -180	60 - 90
Poultry	2	1-1.5	190 - 210	45 - 75
Half Chicken	2	0.5-1	190 - 210	35 - 50
Duck	1	1.5-2	180 - 200	75 - 105
Goose	1	3.5-5	160 - 180	135 - 210
Turkey	1	2.5-3.5	160 - 180	105 - 150
Turkey	1	4-6	140 - 160	150 - 240

DEFROSTING

- Put the food out of the packaging and set it on a plate on the oven shelf.
- Do not cover with a plate or bowl. This can extend the time to defrost very much.
- Put the oven shelf in the first shelf level from the bottom.

Type of food	Shelf	Time in minutes	Final defrosting mins	Comments
Chicken, 1000 g	2	120-140	20-30	Place the chicken on an upturned saucer on a larger plate. Turn half way through.
Meat, 1000g	2	100-140	20-30	Turn half way through.
Meat, 500g	2	90-120	20-30	Turn half way through.
Trout, 150g	2	25-35	10-15	-
Strawberries, 300g	2	30-40	10-20	-
Butter, 250g	2	30-40	10-15	-

Type of food	Shelf	Time in minutes	Final defrosting mins	Comments
Cream, 2 x 2dl	2	80-100	10-15	Cream can be whipped even if it is still slightly frozen.
Cake, 1400g	2	60	60	-

OVEN - CARE AND CLEANING

Warning! Refer to the Safety chapters.

- Clean the front of the appliance with a soft cloth with warm water and cleaning agent.
- To clean metal surfaces use a usual cleaning agent
- Clean the oven interior after each use. Thus you can remove dirt more easily and it does not burn on.
- Clean stubborn dirt with a special oven cleaner.
- Clean all oven accessories (with a soft cloth with warm water and cleaning agent) after each use and let them dry.
- If you have nonstick accessories, do not clean them using an aggressive agents, sharp edged objects or dishwasher. It can destroy nonstick coating!

Stainless steel or aluminium appliances:
Clean the oven door with a wet sponge only. Dry it with a soft cloth.
Do not use steel wool, acids or abrasive materials as they can damage the oven surface. Clean the oven control panel with the same precautions

CATALYTIC WALLS (SELECTED MODELS ONLY)

The walls with a catalytic coating are self-cleaning. They absorb fat which collects on walls while the oven operates.

To support this self-cleaning process heat the oven without any food regularly:

- Turn the oven light on.
- Remove accessories from the oven.
- Set the Conventional Cooking function.
- Set the oven temperature to 250 °C and let oven operate for 1 hour.
- Clean the oven cavity with a soft and damp sponge.

Warning! Do not attempt to clean catalytic surface with oven sprays, abrasive cleaners, soap or other cleaning agents. This will damage the catalytic surface.

Discolouration of the catalytic surface has no effect on catalytic properties.

SHELF SUPPORT RAILS

Removing the shelf support rails

1. Pull the front of the shelf support rail away from the side wall.



2. Pull the rear shelf support rail away from the side wall and remove it.



Installing the shelf support rails

Install the shelf support rails in opposite sequence.

The rounded ends of the shelf support rails must point to the front!

Caution! Make sure that the longer fixing wire is in the front. The ends of the two wires must point to the rear. Incorrect installation can cause damage to the enamel.

CLEANING THE TOP OVEN GLASS PANELS

The door glass on your product can be different in type and shape from what you see in diagrams. The number of glasses can be different.

Removing the glass:

1. Open the door.
2. Push the door trim at both sides to release the clips. Refer to the picture.
3. Remove the glass panels.



To replace the glass obey the procedure in opposite sequence.

CLEANING THE DOOR GLASS PANELS

The door glass on your product can be different in type and shape from what you see in diagrams. The number of glasses can be different.

Removing the glass:

1. Push the door trim at one side to remove it. Refer to the picture.
2. Pull up the trim.
3. Remove the glass panels.



To replace the glass panels obey the procedure in opposite sequence. Before you lower the trim attach the A trim part to the door. Refer to picture.

OVEN LAMP

Warning! There is a danger of electrical shock!

Before you change the oven lamp:

- Switch off the oven.
- Remove the fuses in the fuse box or switch off the circuit breaker.

Put a cloth on the bottom of the oven for protection of the oven light and glass cover.

Replacing the oven lamp

1. You can find the lamp glass cover at the back of the cavity.
   Turn the lamp glass cover counter-clockwise to remove it.
2. Clean the glass cover.
3. Replace the oven lamp with applicable 300°C heat-resistant oven lamp.

Important! Use the same oven lamp type.

4. Install the glass cover.

WHAT TO DO IF…

⚠ **Warning!** Refer to the Safety chapters.

Problem	Possible cause	Remedy
The appliance does not operate	The fuse in the fuse box is released	Control the fuse. If the fuse is released more than one time, refer to a qualified electrician.
The appliance does not operate	The power plug is not correctly put in	Put in the power plug correctly
The appliance does not operate	The earth fault switch is switched off	Switch on the earth fault switch
The appliance does not operate	The Child Lock or Key Lock is on	Refer to "Locking/unlocking the control panel"
The appliance does not operate	The appliance is not activated	Activate the appliance
The appliance does not operate	The clock is not set	Set the clock
The appliance does not operate	The "Automatic cut-out" is on	Refer to “Automatic cut-out”
The food boils or fries too slowly	The cookware is not correct for the heat conductivity	Use correct cookware with good heat conductivity
The signal clock does not work	The time is not set	Set a time
The oven does not heat up	The necessary settings are not set	Control the settings
The oven lamp does not operate	The oven lamp is defective	Replace the oven lamp
The display shows an error code that is not in this list	There is an electronic fault	• Deactivate the appliance with the house fuse or the safety switch in the fuse box and activate it again • If the display shows the error code again, refer to the Customer Care Department
Sound is heard from the cooker after you deactivate it	The sound comes from the cooling fan which prevents the cooker electronics from becoming too hot	No action necessary
The hob display shows —	The fuses are blown	Control the fuses
The oven display shows **"F9"**	The power plug is out of the wall outlet	Put the power plug in the wall outlet and start the cooker again
The oven display shows **"SAFE"**	The Child Lock operates	Deactivate the Key Lock, refer to "Hob - Daily Use" chapter and "The child safety device"
The oven display shows **"LOC"**	The Key Lock operates	Deactivate the Key Lock, refer to "Hob - Daily Use" chapter and "Locking / unlocking the control panel"

If you cannot find a solution to the problem yourself, contact your dealer or the service centre.

The necessary data for the service centre is on the rating plate. The rating plate is on the front frame of the oven cavity.

We recommend that you write the data here:

Model (MOD.) .....

Product number (PNC) .....

Serial number (S.N.) .....

INSTALLATION

⚠ **Warning!** Refer to the Safety chapters.

TECHNICAL DATA

Dimensions	
Height	894 – 912 mm
Width	599 mm
Depth	600 mm
Top oven capacity	40 l
Main oven capacity	74 l

LOCATION OF THE APPLIANCE

You can install your freestanding appliance with cabinets on one or two sides and in the corner.



Minimum distances

Dimension	mm
A	2
B	685

LEVELLING

Use small feet on the bottom of appliance to set same level of cooker top surface with other surfaces



THE ANTI-TILT PROTECTION

⚠ **Caution!** You must install the anti-tilt protection (A+B). If you do not install it the appliance can tilt.
Before you install anti-tilt protection, adjust the appliance to the correct height.

The anti-tilt protection has two parts (A+B). You can find the anti-tilt protection (B) on right or left side of the rear wall of the appliance (See fig. 1). You must install the anti-tilt protection (A) on the wall. The distance of the hole of the anti-tilt protection (A) from the floor is about 816 mm. Make sure you install the anti-tilt protection (A) at the correct height. Screw it into the solid material or use applicable reinforcement.
Check that the anti-tilt protection projects minimum 20 mm into the hole in the back of the appliance (B) when you push the appliance (See fig. 2). If the space between the bench cupboards is greater than the width of the appliance, you must adjust the side measurement to centre the appliance. Make sure that the surface behind the appliance is smooth.



ELECTRICAL INSTALLATION

⚠ **Warning!** Only a qualified and competent person must do the electrical installation.

ⓘ The manufacturer is not responsible if you do not follow safety precautions from the chapter "Safety information".

This appliance is supplied without a main plug or a main cable.

COVERING TERMINAL BOARD

The recommended cross-section area is six square millimetres (6 mm²).
When you refit the mains terminal cover, make sure that the lower tabs are located inside the bottom edge of the aperture, before you fix the two screws into the top edge of the mains terminal cover.



Make sure that the cover is securely fastened.

ⓘ To open the cover of terminal board obey the procedure in opposite sequence.

TERMINAL BOARD

Make sure that the links are fitted as shown.



ⓘ Do not remove blanking plates.

ENVIRONMENT CONCERNS

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be taken to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local council, your household waste disposal service or the shop where you purchased the product.

Packaging material
The packaging material is environmentally-friendly and recyclable. Plastic parts are marked with international abbreviations such as PE, PS, etc. Dispose of the packaging material in the containers provided for this purpose at your local waste management facility.

GB IE GREAT BRITAIN & IRELAND - GUARANTEE/CUSTOMER SERVICE

STANDARD GUARANTEE CONDITIONS:

We, Electrolux, undertake that if within 12 months of the date of the purchase this Electrolux appliance or any part thereof is proved to be defective by reason only of faulty workmanship or materials, we will, at our option repair or replace the same FREE OF CHARGE for labour, materials or carriage on condition that:

- Appliance has been correctly installed and used only on the electricity supply stated on the rating plate.
- Appliance has been used for normal domestic purposes only, in accordance with manufacturer's instructions.
- Appliance hasn't been serviced, maintained, repaired, taken apart or tampered with by person not authorised by us.
- Electrolux Service Force Centre must undertake all service work under this guarantee
- Any appliance or defective part replaced shall become the Company's property.
- This guarantee is in addition to your statutory and other legal rights.

Exclusions

- Damage, calls resulting from transport, improper use, neglect, light bulbs, removable parts of glass, plastic.
- Costs for calls to put right appliance which is improperly installed, calls to appliances outside United Kingdom.
- Appliances found to be in use within a commercial environment, plus those which are subject to rental agreements.
- Products of Electrolux manufacturer that are not marketed by Electrolux

Service and Spare Parts. Please contact your local Service Force Centre: **08445 616 616**(Call will be routed to Service Force Centre covering your postcode area). For address of local Service Force Centre and further information, please visit: **www.serviceforce.co.uk** Before calling out an engineer, please ensure you have read the details under the heading "What to do if... / Troubleshooting". When you contact the Service Force Centre you will need to give the following details: Your name, address and postcode, your telephone number, clear concise details of the fault, model and serial number of the appliance (found on the rating plate), the purchase date. Please note a valid purchase receipt or guarantee documentation is required for in guarantee service calls.

Customer Care. Please contact our Customer Care Department: Electrolux Major Appliances, Addington Way, Luton, Bedfordshire, LU4 9QQ or visit our website at www.electrolux.co.uk

Customer Care Department,	Tel: (Calls may be recorded for training purposes)
Electrolux	08445 613 613
AEG-Electrolux	08445 611 611
Zanussi-Electrolux	08445 612 612

For Customer Service in The Republic of Ireland please contact us at the address below:

Electrolux Group (Irl) Ltd, Long Mile Road, Dublin 12, Republic of Ireland
Tel: +353 (0)1 4090751, Email: service.eid@electrolux.ie

EUROPEAN GUARANTEE

GB This appliance is guaranteed by Electrolux in each of the countries listed at the back of this user manual, for the period specified in the appliance guarantee or otherwise by law. If you move from one of these countries to another of the countries listed, the appliance guarantee will move with you subject to the following qualifications:-

- The appliance guarantee starts from the date you first purchased the appliance

which will be evidenced by production of a valid purchase document issued by the seller of the appliance.
- The appliance guarantee is for the same period and to the same extent for labour and parts as exists in your new country of residence for this particular model or range of appliances.
- The appliance guarantee is personal to the original purchaser of the appliance and cannot be transferred to another user.
- The appliance is installed and used in accordance with instructions issued by Electrolux and is only used within the home, i.e. is not used for commercial purposes.
- The appliance is installed in accordance with all relevant regulations in force within your new country of residence.

The provisions of this European Guarantee do not affect any of the rights granted to you by law.

WWW.ELECTROLUX.COM

Albania	+355 4 261 450	Rruga “Kavajës”, ish-parku autobuzëve, Tiranë
Belgique/België/Belgien	+32 2 7162444	Raketstraat 40, 1130 Brussel/Bruxelles
Česká Republika	+420 261 302 261	Budějovická 3, Praha 4, 140 21
Danmark	+45 70 11 74 00	Strevelinsvej 38-40, 7000 Fredericia
Deutschland	+49 180 32 26 622	Fürther Str. 246, 90429 Nürnberg
Eesti	+37 2 66 50 030	Pärnu mnt. 153, 11624 Tallinn
España	+34 902 11 63 88	Carretera M-300, Km. 29,900 Alcalá de Henares Madrid
France	08 92 68 24 33 (0.34€/ min)	www.electrolux.fr
Great Britain	+44 8445 616 616	Addington Way, Luton, Bedfordshire LU4 9QQ
Hellas	+30 23 10 56 19 70	4, Limnou Str., 54627 Thessaloniki
Hrvatska	+385 1 63 23 338	Slavonska avenija 3, 10000 Zagreb
Ireland	+353 1 40 90 753	Long Mile Road Dublin 12
Italia	+39 (0) 434 558500	Corso Lino Zanussi, 30 - 33080 Porcia (PN)
Latvija	+371 67313626	Kr. Barona iela 130/2, LV-1012, Riga
Lietuva	+370 5 278 06 03	Ozo 10a, LT-08200 Vilnius
Luxembourg	+352 42 431 301	Rue de Bitbourg, 7, L-1273 Hamm
Magyarország	(06-1)467-3205 +361 252 1773	H-1142 Budapest XIV, Erzsébet Királyné útja 87
Nederland	+31 17 24 68 300	Vennootsweg 1, 2404 CG - Alphen aan den Rijn
Norge	+47 81 5 30 222	Risløkkvn. 2 , 0508 Oslo
Österreich	0810 955030	Herziggasse 9, 1230 Wien
Polska	+48 22 43 47 300	ul. Kolejowa 5/7, 01–217 Warszawa
Portugal	+35 12 14 40 39 39	Quinta da Fonte - Edifício Gonçalves Zarco - Q 35 -2774-518 Paço de Arcos

Romania	+40 21 451 20 30	Str. Garii Progresului 2, S4, 040671 RO
Schweiz - Suisse - Svizzera	0848 848 111	Industriestrasse 10, CH-5506 Mägenwil
Slovenija	+38 61 24 25 731	Gerbičeva ulica 110, 1000 Ljubljana
Slovensko	+421 2 32 14 13 34-5	Electrolux Slovakia s.r.o., Electrolux Domáce spotrebiče SK, Galvaniho 17/B, 821 04 Bratislava
Suomi	030 600 5200 Lankapuhelinverkosta 0,0828€/puhelu+0,032€/min Matkapuhelinverkosta 0,192€/min	
Sverige	+46 (0)771 76 76 76	Electrolux Service, S:t Göransgatan 143, S-105 45 Stockholm
Türkiye	+90 21 22 93 10 25	Tarlabaşı caddesi no : 35 Taksim İstanbul
Россия	8-800-200-3589	129090 Москва, Олимпийский проспект, 16, БЦ "Олимпик"
Україна	+380 44 586 20 60	04074 Київ, вул.Автозаводська, 2а, БЦ "Алкон"

www.electrolux.com/shop

892957244-A-462012